

PERA

PERACRETE

For large repairs, thin toppings in factories and warehouses, when hard tough and non shrink concrete is needed.



PERACRETE

**10MM-25MM
THICKNESS**



SPESIFIKASI

Nama Produk

Lapisan beton tipis tanya deformasi

Masa Berlaku Produk

2023-12-31

Merek

Peracrete

No.Produk Penyedia

Pera

Unit Pengukuran

Sak 25 kg

Nama pemilik sertifikat

PT Pera Abadi Sentausa

Finishes



Polished



Colour hardener & troweled



Bushhammer



Exposed



Cream finish



Salt and Pepper



No.SNI

Tidak ada

Batu

Max agg. 2mm

Jenis paving

Industri dan desiratif

Ketebalan

1cm-25cm

Mutu Beton subfloor min.

K200

Cara Pengiriman

Truk

Pengalaman kerja

Memiliki Pengalaman akerja

Ketebalan

10 - 25 mm sebelum dipoles

Ratio air - semen

0.32

Air

3.2L-3.4 Litre per 25kg bag



kekuatan

55 MPa - 75 MPa Tergantung pada ba

Lentur

9 MPa - 15 Mpa Tergantung pada ba

Polishing

Satu hingga dua hari setelah casting

Ingredients

Batu, mill, pasir, advanced admixtures.

Percampuran

Cukup tambahkan air 3.2 liter per 25 kg



PT Pera Abadi Sentosa
Tel 08113380020
Web www.peracrete.com
info@peracrete.com

Product information

Peracrete is a pre mixed uniquely

Engineered into a super strong shrink resistant

Self bonding thin topping for applications 12mm -30mm

In thickness. Each bag will produce 1sqm2 at 12mm thick, To be screeded flat and mechanical floated and polished by power trowel pizza float pan and with steel trowel.

Peracrete. Mixing Instructions.

Always use full bags for mixing.

Water cement ratio is 0.32

3.2 Litres of water per 25 kg bag

Never add more water. keep consistent.

Eg.If you mix 2 bags at a time x2 water =6.4 Litre

Use hand held paddle mixer mix for 5 minutes.

Or use rotary or pan mixer mix for 5 minutes.

Ready to use. Please refer to Peracrete application Instructions In Technical data sheet.

In Brief :

Prepared floor must be open concrete surface roughed to CSP 6 - CSP 9.

Cleaned of all dust and debris and loose materials.

Then well soaked with water.remove standing or pooled water With sponge or wet and dry Vacuum.

Apply Peracrete while damp ensure no dry spots appear before Applying.

Screed off flat, when it has set enough to take the weight of

A person use peramax finishing aid to lightly spray over surface and power float with pizza pan you may at this stage dust over colour hardener for cream finish you may use just colour with out Hardener polymer as peramax will Harden the surface. and then use power trowel to finish and polish shine.